

Hardware Mounting Locations

Locks, Latches, Roller Latches and Double Handle Sets	38" – 42" (965 mm – 1067 mm) Centerline of Lock Strike from Bottom of Frame	
Rim and Mortise Panic Devices		
Cylindrical and Mortise Deadlocks ⁽¹⁾	48" (1219 mm) to Centerline of Strike from Bottom of Frame	
Push Plates	Centerline 45" (1143 mm) from Bottom of Frame	
Pull Plates	Centerline of Grip @ 42" (1067) from Bottom of Frame	
Combination Push Bar	Centerline of 42" (1067 mm) from Bottom of Frame	
Hospital Arm Pull	Centerline of Lower Base is 45" (1143 mm) from Bottom of Frame with Grip Open at Bottom	
Hinges	Top	Up to 11-3/4" (298.5 mm) from Rabbet Section of Frame to Centerline of Hinge
	Bottom	Up to 13" (330.2 mm) from Bottom of Frame to Centerline of Hinge
	Intermediate	Equally Spaced Between Top and Bottom Hinges

⁽¹⁾ Cylindrical and Mortise Deadlock strikes shall be located at 48" (1219 mm) from the bottom of the frame unless otherwise specified.